

BROTHER LC-41 Cartridge - 'LOW INK' MESSAGE

ISSUE:

Recycled LC-41 cartridge is installed - ink level displays 'low ink'.

SOLUTION:

To remove 'Low Ink' messages, perform the following:

- 1.) Remove inkjet cartridge from printer;
- 2.) Unplug the printer (with cover open);
- 3.) Re-plug the printer (with cover open);
- 4.) Replace inkjet cartridges inside printer in this order: (K,Y,M,C); close lid;
- 5.) Printer goes through cleaning process.

Printer messages should now be cleared.

BROTHER Printer models that use LC-41 Cartridges and may show 'Low Ink' message:

Brother All-in-One Machines	DCP-110C, DCP-120C, MFC-210C, MFC-3240C, MFC-3340CN, MFC-410CN, MFC-420CN, MFC-5440CN, MFC-5840CN, MFC-620CN, MFC-640CW, MFC-820CW
Brother Copy Machines	DCP-110C, DCP-120C
Brother Fax Machines	Intellifax 1840C, Intellifax 1940CN, Intellifax 2440C