

## "Low Ink" Warnings On Dell AIO 922, 924 & 926

This section helps consumers understand and respond to "low ink" warnings which sometimes appear prematurely after refilling and then re-installing a cartridge on Lexmark® and Dell® printers.

Once an OEM cartridge is inserted into your printer, the printer begins to track the ink used for that particular cartridge. When a cartridge has used about 80% of its ink, the printer may begin to send the user "your ink level is low" warning messages. After the cartridge is refilled, the printer may continue to send out these warning messages. The low ink warning is very common in Dell and Lexmark printers. There is no chip to reset. It is in the electronics of the cartridge.

**These warning messages may simply be ignored, and the printer should continue to operate normally.** However, if you wish to **disable** the "Low Ink" warning messages, please follow instruction below.

To disable the "Low Ink" warning messages from your PC do the following:

1. From the WINDOWS™ click START Menu → Programs → Dell Printers → Dell Photo AIO Printer 922 → Dell All In One Center
2. Click on "Maintain / Troubleshoot" → Click on "Ink Level" → Click on "Advanced" tab → Click on "More Option" command button
3. Click on the circle option button "Never display the printing status"
4. Click on the circle option button "Never display low ink messages"  
(Apply for Photo AIO 926 printer only)
5. Click OK to apply the setting change and close all application.

***NOTE: This operation will disable all Printing Status and Low Ink message display from your PC. This operation can be reversed by repeating these steps and checking the "Display Printing Status minimized in the taskbar" "Display all low ink messages" option button.***